




How to load token on Pre-Paid Electricity Meter

Use the black cable to plug the CIU Box into a normal electricity plug point and turn on the plug. (Make sure the black cable is also plugged into the CIU box!)




Open the plastic lid to expose the number keypad

It will look like this:

 <p>The image shows a close-up of the HEXING electricity meter keypad. The LCD screen displays a menu with two options: '1. Messages' and '2. AutoScroll'. Below the screen is a numeric keypad with buttons for digits 1-9, 0, and left and right arrows. A green LED indicator is lit. The meter's body is white with 'HEXING' printed at the top.</p>	<p>Press 2 on the keypad.</p> <p>Key in the Token number.</p> <p>Press the bottom right arrow to accept the number.</p>
 <p>The image shows the HEXING electricity meter screen displaying 'ACCEPT 67.00kWh'. A green checkmark is visible on the right side of the screen. Below the screen, the text 'CIU EV' and 'HEXING' are visible. A green LED indicator is lit.</p>	<p>The screen will then display the number of kWh loaded.</p> <p>To check the new balance, then press 2, then 801, then bottom right arrow.</p>
 <p>The image is a close-up of the keypad, focusing on the left arrow button. A black arrow points from the text to this button.</p>	<p>WRONG NUMBER:</p> <p>If you key in a wrong number, press the bottom left arrow to go back one number at a time.</p>

--	--

How to check the balance of units (Kwh)on Prepaid Meter

	<p>ON MAIN METER</p> <p>This can be done <u>on the actual meter</u> by pressing the button at the top right of the unit.</p> <p>Each time you press the button, the reading will scroll to a different measurement.</p> <p>Read the first one that shows “kW h” at the bottom right of the screen. (there are 2 kWh readings).</p>
	<p>ON CIU BOX</p> <p>It can also be done on the CIU Box, by plugging it into an electricity plug and pressing 2 when the first menu comes up (as when loading a Token, above).</p> <p>Then type in 801.</p> <p>Press the arrow at bottom right.</p>
	<p>The balance of Units will display on the screen.</p>